



Ref. ABR-111

## Soft hook-and-loop interface pad for sanders

Perforated interface pad that protects the backing pad and follows curves, in 5 or 6 in.

Soft interface pad that fits between the sander backing pad and the abrasive disc. Its holes stop dust clogging the backing pad, make cleaning easier and extend the life of the tool. Available in 5 and 6 in.

### Technical specifications

|              |                         |
|--------------|-------------------------|
| Diameters    | 5 in, 6 in              |
| Hole pattern | 5 + 1, 6 + 1 and others |
| Density      | Soft                    |
| Colours      | Black                   |

### How to use

- Sanding curved surfaces with an orbital sander
- Protecting the sander backing pad

### Packaging and delivery

| Size | Reference  | Pack quantity                |
|------|------------|------------------------------|
| 5 in | ABR-111-01 | 100 pieces per carton (2 kg) |
| 6 in | ABR-111-02 | 100 pieces per carton (3 kg) |

Carton dimensions : 45 × 45 × 30 cm · Carton gross weight : 2 kg (5 in); 3 kg (6 in)

This product is available from Humming distributors. Find the one nearest to you.